



Position	Amount	Type number	Description	PG
1	1	341703790	Cap screw	13
2	1	341031860	Clamping flange	18
3	1	341031870	Clamping flange	17
4	4	341703840	Tap tite screw M 3 X 8	10
5	1	339132120	Retraining sheet	15
6	1	315417280	Pendulum guard	28
7	1	315417270	Saw housing	26
8	1	341703810	Countersunk screw	11
9	1	339040870	Rubber ring	10
10	1	315417130	Saw housing	30
11	3	141120070	Fill. head screw	10
12	2	141130650	Hexagonal lock nut	12
13	1	316044990	Spindle lock	14
14	1	342003230	Pressure spring	10
15	1	316038050	Gear-box cpl.	44
16	1	342003310	Pressure spring	10
17	1	343397750	Switch-on lock	10
18	1	343408810	Electronic switch,DC 18V	49
19	1	316038060	Gear-box cpl.	48
20	4	141116990	Self-tap. fill. h. screw	12
21	1	343397740	LED	10
22	1	315013380	Motor housing	34
23	10	141118730	Self-tap. fill. h. screw	10
24	1	338121830	Metabo label 40x14 ULA 14.4-18	10
25	5	141120340	Screw	10
26	1	343398010	Motor cover	14
27	4	141120470	Self-tap. fill. h. screw	10
28	1	338052190	Rating plate	10
29	1	141119480	Fill. head screw(DIN 7985)	10
30	1	343398020	Guard lever	10
31	1	342021920	Spring left	13
32	1	331050820	Parallel guide	21
33	1	343396920	Exhaust nozzle	15
34	1	343394770	Pressure plate	10
35	1	343394790	Switch slide	10
36	1	342021670	Spring clip	10
37	1	344097060	Rubber plug	10
38	1	141119960	Truss head screw	12
39	1	341703830	Fillister head screw M 6X40	11
40	2	341100970	Thumb-nut	13
41	2	141150960	Washer	10

42	1	141116050	Truss head screw	12
43	1	341111920	Thumbscrew	13
44	1	141150020	Washer	10
45	1	342003240	Pressure spring	10
46	1	141113200	Fillister head screw	10
47	1	141130070	Hexagonal nut	10
48	1	316037290	Guide plate cpl.	31
49	1	344161530	Hexagonal key	12
50	1	338121750	Warning Label serial 40x14	10
1001	1	338504870	Wiring diagram	

spareparts.com.au

