



Position	Amount	Type number	Description	PG
1	1	314000960	Anti-vibration handle,M 14	28
2	1	341100660	Self locking nut	14
3	1	316025290	Bevel gear	35
4	1	341011510	Spacer ring	17
5	1	143192440	Felt ring	14
6	1	339070080	Cover washer	12
7	1	143110670	Ball bearing, 12x37x12	25
8	1	339005920	Bearing cover	13
9	1	310009880	Armature compl.,230 V	48
10	1	143113400	Ball bearing, 8x22x7	22
11	1	344094080	Rubber bearing	12
12	1	339150950	Baffle	14
13	2	141121680	Self-tap. fill. h. screw	10
14	1	311009590	Field coil	35
15	2	344493690	Strand	12
16	4	141119370	Self-tap. fill. h. screw	10
17	1	141122020	Fillister head screw	10
18	1	316031720	Gear housing cpl.	34
19	1	141119850	Fillister head screw	10
20	2	339060140	Sealing ring	12
21	1	343376490	Bearing flange	26
23	4	141121640	Fill. head screw(DIN 7985)	10
24	1	341602980	Spindle shaft	29
25	1	316039470	Wheel guard cpl.	33
26	1	341031160	Clamping flange	22
27	1	341106900	Flange nut	20
28	1	338117340	Indication label	10
29	3	341702050	Screw	10
30	2	343376430	Cover	12
31	1	316033950	Carbon brush	25
32	2	343000770	Brush guide	18
33	1	315012760	Motor housing	27
35	1	343368540	Handle (upper+under part)	28
36	4	141116020	Self-tap fill h screw	12
37	1	343253890	Condenser	20
38	1	343404130	Switch	32
39	1	339127730	Cable clip	10
41	1	344094550	Cable sleeve	13
42	1	344490850	Cable with plug	27
43	1	344160840	Pin spanner	17
44	1	338115980	Metabo label	13

45	1	338047630	Rating plate	10
46	1	343369570	Locking lever	13
47	1	342002170	Pressure spring	10
48	1	142110090	Insulating sleeve	10
49	1	344094980	Flat gasket ring	10
50	1	343253830	Starting resistance	24
52	1	141131020	Square nut	12
53	1	141111390	Cap screw	12
57	1	343370770	Sealing washer	10
58	1	343376440	Push button	13
59	1	342001730	Pressure spring	10
60	1	341003970	Guide bush	15
61	1	341513810	Thrust bolt	12
880	1	344130910	Grease 100G	24
1001	1	338502170	Diagram	

