





Model No: BO4561

Parts List

ID	Part No	Name	Qty	Notes
1	643552-4	BRUSH HOLDER 5-8	2	
2	***	***	***	Click for Technical Bulletin 85070
3	211021-9	BALL BEARING 607LLB	1	
4	517084-6	ARMATURE ASS'Y 240V	1	
5	182777-0	HOUSING SET	1	
6	599320-2	FIELD ASS'Y 240V	1	
7	253214-2	FLAT WASHER 9	1	
8	211092-6	BALL BEARING 629DDW	1	
9	858238-9	NAME PLATE BO4561	1	
10	241658-8	FAN 63	1	
11	213051-6	DUST SEAL 10	1	
12	211066-7	BALL BEARING 6200LLB	1	
13	410752-9	BAFFLE PLATE	1	
14	265871-4	TAPPING SCREW BT 4X16	2	
15	***	***	***	Click for Technical Bulletin 55112
16	911118-1	PAN HEAD SCREW M4X12	4	
17	152478-4	BASE COMPLETE	1	
18	912117-6	COUNTERSUNK HEAD SCREW M4X12	1	
19	253825-3	FLAT WASHER 6	1	
20	262512-3	RUBBER SLEEVE 48	1	
21	***	***	***	Click for Technical Bulletin 92332
22	182777-0	HOUSING SET	1	
23	265872-2	TAPPING SCREW BT 4X50	2	
24	265875-6	TAPPING SCREW BT 4X25	1	
25	265876-4	TAPPING SCREW BT 4X40	1	
26	***	***	***	Click for Technical Bulletin 57181
27	687063-9	CORD CLAMP	1	
28	682502-4	CORD GUARD 8-85	1	
29	666453-9	POWER SUPPLY CORD 1.0-2-2.0	1	
30	***	***	***	Click for Technical Bulletin 69726
31	166027-1	DUST BAG	1	
32	654532-5	TERMINAL BLOCK 1P	1	
1001	192352-4	ABRASIVE PAPER SET	1	
1002	192655-6	ABRASIVE PAPER SET	1	