





Model No: HR262TD

Parts List

ID	Part No	Name	Qty	Notes
7	921923-8	HEX. BOLT M8X120	1	
8	345280-4	HEX. WASHER	1	
9	417630-4	GRIP BASE	1	
10	158057-6	GRIP 36 COMPLETE	1	
13	450980-4	CHANGE LEVER	1	
14	233279-0	COMPRESSION SPRING 4	1	
15	453706-3	LOCK BUTTON	1	
16	213278-8	O RING 17	1	
17	158945-7	GEAR HOUSING COMPLETE	1	
18	266351-3	TAPPING SCREW 4X35	4	
19	153290-5	NEEDLE BEARING COMPLETE	1	
20	961017-7	STOP RING E-3	2	
21	417796-0	GUIDE BASE	1	
22	233344-5	COMPRESSION SPRING 4	2	
23	163430-7	LOCK PLATE COMPLETE	1	
24	266374-1	TAPPING SCREW 4X25	2	
25	233929-7	RING SPRING 29	1	
26	267460-1	WASHER 31	1	
27	233401-9	COMPRESSION SPRING 32	1	
28	227109-5	SPUR GEAR 51	1	
30	158307-9	TOOL HOLDER GUIDE COMPLETE	1	
31	267229-3	FLAT WASHER 28	1	
32	331769-8	SLEEVE 9	1	
33	324796-2	IMPACT BOLT	1	
34	324402-9	RING 10	1	
35	421955-0	CUSHION RING 13	1	
36	324216-6	O RING CASE	1	
37	213073-6	O RING 9	1	
38	233917-4	RING SPRING 28	1	
39	324214-0	STRIKER	1	
40	213227-5	O RING 16	1	
41	318132-2	PISTON CYLINDER	1	
42	346036-8	GUIDE PLATE	1	
43	324215-8	PISTON JOINT	1	
44	234098-7	COMPRESSION SPRING 14	1	
45	211012-0	BALL BEARING 606ZZ	1	
46	961003-8	RETAINING RING S-7	1	
47	233343-7	COMPRESSION SPRING 7	1	
48	227179-4	SPUR GEAR 10	1	
49	325976-3	CAM SHAFT	1	
50	331992-5	CLUTCH CAM	1	
51	219014-0	SWASH BEARING 10	1	
52	325640-6	SLEEVE 9	1	
53	227549-7	SPIRAL BEVEL GEAR 26	1	
54	266273-7	HEX. SOCKET HEAD BOLT M4X12	2	
55	346038-4	BEARING RETAINER B	1	



Model No: HR262TD

ID	Part No	Name	Qty	Notes
56	211032-4	BALL BEARING 608ZZ	1	
57	324212-4	RING 8	1	
58	961011-9	STOP RING E-4	1	
59	941102-2	FLAT WASHER 5	1	
60	233342-9	COMPRESSION SPRING 6	1	
61	345220-2	CHANGE PLATE	1	
62	922148-7	HEX. SOCKET HEAD BOLT M4X25	2	
63	158944-9	INNER SUPPORT COMPLETE	1	
64	213728-3	O-RING 68	1	
65	318392-6	INNER HOUSING	1	
66	443143-9	FILTER	1	
67	424185-2	CAP	1	
68	234097-9	COMPRESSION SPRING 10	2	
69	266273-7	HEX. SOCKET HEAD BOLT M4X12	2	
70	213231-4	OIL SEAL 15	1	
71	213437-4	O RING 28	1	
72	632828-4	YOKE UNIT	1	
73	961082-6	RETAINING RING WR12	1	
74	331596-3	SLEEVE 12	1	
75	211131-2	BALL BEARING 6001DDW	1	
76	961016-9	STOP RING E-10	1	
77	346037-6	BEARING RETAINER A	1	
78	519235-7	ARMATURE ASS'Y 36V	1	
79	240037-7	FAN 44	1	
80	210022-4	BALL BEARING 626DDW	1	
81	631850-8	LIGHT CIRCUIT	1	
82	638945-8	BRUSH HOLDER COMPLETE	1	
83	643829-7	HOLDER CAP	2	
84	195023-2	CARBON BRUSH SET CB-442	1	
85	266326-2	TAPPING SCREW 4X18	2	
86	638945-8	BRUSH HOLDER COMPLETE	1	
87	638978-3	TERMINAL UNIT	1	
88	346039-2	SUPPORT PLATE	1	
89	187231-9	HOUSING SET	1	
90	188639-0	HANDLE SET	1	
91	450981-2	SWITCH LEVER	1	
92	650619-1	SWITCH C3HZ-2A-PBLM	1	
93	450979-9	F/R CHANGE LEVER	1	
94	256261-2	PIN 6	2	
95	188639-0	HANDLE SET	1	
96	266326-2	TAPPING SCREW 4X18	4	
97	897506-5	HR262TD SERIAL NO. LABEL	1	
98	344903-1	VIBRATION ISOLATOR PLATE	1	
99	187231-9	HOUSING SET	1	
100	897504-9	HR262TD NAME PLATE	1	
101	266326-2	TAPPING SCREW 4X18	9	
102	893038-0	CLEAR LABEL	1	
103	893072-0	CLEAR LABEL	1	
110	194080-7	TOOL HOLDER SET	1	



Model No: HR262TD

ID	Part No	Name	Qty	Notes
111	286263-4	CAP 35	1	
112	233940-9	RING SPRING 19	1	
113	418217-5	CHUCK COVER	1	
114	345333-9	STOPPER	1	
115	216022-2	STEEL BALL 7.0	1	
116	345187-4	GUIDE WASHER	1	
117	233916-6	CONICAL COMP. SPRING 21-29	1	
118	267279-8	FLAT WASHER 21	1	
119	324355-2	TOOL HOLDER	1	
120	216013-3	STEEL BALL 6	2	
121	231669-1	TORSION SPRING 31	1	
122	345334-7	CHANGE RING	1	
123	418218-3	CHANGE COVER	1	
124	216018-3	STEEL BALL 5.0	1	
125	345335-5	LEAF SPRING	1	
126	267270-6	FLAT WASHER 24	1	
127	233924-7	RING SPRING 21	1	
1001	194079-2	DRILL CHUCK SET	1	
1002	194683-7	GREASE VESSEL SET	1	
1003	324219-0	DEPTH GAUGE	1	
1004	443122-7	CLOTH	1	
1005	195497-7	BATTERY BL3622A SET	2	
1006	451153-2	BATTERY COVER	1	
1007	***DC36WA	DC36WA BATTERY CHARGER	1	
1008	141407-2	PLASTIC CARRYING CASE COMPLETE	1	
1009	800M05-6	HR262TDWBE PLASTIC CASE LABEL	2	