





Parts List

ID	Part No	Name	Qty	Notes
1	163100-8	SHAFT LOCK	1	
2	411466-3	BAFFLE PLATE	1	
3	213459-4	O RING 32	1	
4	***	***	***	Click for Technical Bulletin 82574
5	241514-2	FAN 92	1	
6	***	***	***	Click for Technical Bulletin 51212
7	681635-2	INSULATION WASHER	1	
8	211068-3	BALL BEARING 6200LB	1	
9	911290-9	PAN HEAD SCREW M5X65	2	
10	263002-9	RUBBER PIN 4	1	
11	***	***	***	Click for Technical Bulletin 51212
12	157740-2	MOTOR HOUSING	1	
13	855945-5	NAME PLATE LS1020	1	
14	953106-2	RIVET 0-5	4	
16	251335-4	+ PAN HEAD SCREW M5X80	4	
17	911158-9	PAN HEAD SCREW M4X30	3	
18	***	***	***	Click for Technical Bulletin 85070
19	643650-4	BRUSH HOLDER CAP 6.5-13.5	2	
20	911128-8	PAN HEAD SCREW M4X16	2	
21	411467-1	CLAMP COVER	1	
22	911133-5	PAN HEAD SCREW M4X18	2	
23	687000-3	STRAIN RELIEF	1	
24	645006-7	NOISE SUPPRESSOR	1	
25	410839-7	HANDLE COVER	1	
26	911101-8	PAN HEAD SCREW M4X6	1	
27	651135-6	SWITCH SGE220RD-1	1	
28	411468-9	CLAMP BASE	1	
29	682505-8	CORD GUARD 10-90	1	
30	***	***	***	Click for Technical Bulletin
31	251953-8	-SCREW (FLAT POINT)M10X70	1	
32	941252-3	FLAT WASHER 10	1	
33	931503-2	HEX. NUT M10	1	
34	421328-7	CUSHION	1	
35	251399-8	+ PAN HEAD SCREW M5	1	
36	911124-6	PAN HEAD SCREW M4X14	2	
37	254203-0	KEY 4	1	
38	912327-5	COUNTERSUNK HEAD SCREW M6X18	2	
39	342968-7	BAND HOLDER	2	
40	410723-6	CARRYING BAND	1	
41	343465-6	GUIDE ARM	1	
42	253022-1	FLAT WASHER 8	1	
43	251331-2	+ PAN HEAD SCREW M6	1	
44	253715-0	FLAT WASHER 6	1	
45	257157-0	RING 8	1	
46	251331-2	+ PAN HEAD SCREW M6	1	
47	923901-4	CAP SQUARE NECK BOLT M5X8	1	



Model No: LS1020

ID	Part No	Name	Qty	Notes
48	342971-8	PLATE	1	
49	231933-0	SPRING 26	1	
50	265324-3	HEX. FLANGE HEAD BOLT M8X12	1	
51	414032-5	SAFETY COVER	1	
52	942101-7	SPRING WASHER 5	1	
53	931202-6	HEX. NUT M5	1	
54	151287-8	BLADE CASE COMPLETE	1	
55	251644-1	HEX. FLANGE HEAD BOLT M8X20	1	
56	224118-5	OUTER FLANGE 55	1	
57	224206-8	INNER FLANGE 55	1	
58	911231-5	PAN HEAD SCREW M5X20	4	
59	285660-1	BEARING RETAINER 71	1	
60	321921-6	SPINDLE	1	
61	253328-7	THIN WASHER 17	1	
62	211256-2	BALL BEARING 6203LLB	1	
63	312982-7	BEARING BOX	1	
64	221712-4	HELICAL GEAR 41	1	
65	961057-5	RETAINING RING S-17	1	
66	212101-4	NEEDLE BEARING 1210	1	
67	157855-5	GEAR HOUSING	1	
68	921541-2	HEX. BOLT M10X25	4	
69	316067-1	GUIDE FENCE	1	
70	163271-1	SUPPORTER	1	
71	911321-4	PAN HEAD SCREW M6X16	1	
72	251954-6	SET SCREW M10	1	
73	251698-8	HEX. BOLT M16	1	
74	253771-0	FLAT WASHER 16	1	
75	154354-8	ARM COMPLETE	1	
76	231530-2	TORSION SPRING 32	1	
77	341511-9	STOPPER	1	
78	253948-7	WAVE WASHER 8	1	
79	253309-1	THIN WASHER 8	1	
80	251267-5	+ PAN HEAD SCREW M6	1	
81	253771-0	FLAT WASHER 16	1	
82	252044-8	HEX. NUT M16-24	1	
83	414236-9	FENCE PLATE	1	
84	410704-0	KERF BOARD	1	
85	312511-6	SET PLATE	1	
86	321790-5	HOLDER	1	
87	251804-5	SCREW M6X13	1	
88	151221-8	BASE COMPLETE	1	
89	341912-1	NUT HOLDER	1	
90	911216-1	PAN HEAD SCREW M5X14	1	
91	342967-9	SET PLATE	1	
92	341911-3	PROTECTOR	2	
93	321490-7	RELEASE NUT R	1	
94	321491-5	RELEASE NUT L	1	
95	***	***	***	Click for Technical Bulletin 57946
96	271272-6	KNOB 45	1	



Model No: LS1020

ID	Part No	Name	Qty	Notes
97	253744-3	FLAT WASHER 12	1	
98	315891-9	WISE PLATE	1	
99	253047-5	FLAT WASHER 6	1	
100	911317-5	PAN HEAD SCREW M6X14	1	
101	911108-4	PAN HEAD SCREW M4X8	2	
102	816173-7	INDICATION LABEL	1	
103	342823-3	PLATE	1	
104	273481-3	GRIP 32	1	
105	342824-1	LATCH SPRING	1	
106	911246-2	PAN HEAD SCREW M5X28	1	
107	321789-0	LATCH PIN	1	
108	921441-6	HEX. BOLT M8X25	2	
109	232091-5	LEAF STAY	1	
110	311772-5	TURNING STAY	1	
111	924311-8	WING BOLT M6X12	2	
112	321790-5	HOLDER	1	
113	922457-4	HEX. SOCKET HEAD BOLT M8X35	2	
114	942201-3	SPRING WASHER 8	2	
115	311788-0	TURN BASE	1	
116	951113-9	SPRING PIN 4-18	2	
117	343492-3	BLADE STOPPER	2	
118	911206-4	PAN HEAD SCREW M5X10	2	
119	253139-0	FLAT WASHER 8	1	
400	782212-4	SOCKET WRENCH 13	1	
402	122351-2	DUST BAG ASS'Y	1	
403	410602-8	FASTENER	1	
500	***	***	***	Click for Technical Bulletin 57946