


per
for**RYOBI**

UN001798-FB

4

Pos.	Cod. Part n°	Denominazione	Description	Q.tà Q.ty	Note Vedi / See
1	1983250	Piattello oscillante	Wobble plate	1	
2	1981210	Cuscinetto	Bearing	1	
3	1260750	Anello tenuta	Seal ring	1	
4	2320830	Vite TE M 5x130	Screw	4	
5	1982040	Flangia pompa	Flange	1	
6	1980340	OR ø 83,8x2,62	O-Ring	1	
7	1460460	Vite TC M 5x16	Screw	2	
8	1680960	Rondella ø 5,5	Washer	2	
9	1460590	Cuscinetto	Bearing	1	
10	1460040	Scudo motore	Motor shield	1	
11	1461200	Anello tenuta	Seal ring	1	
12	1460370	Ventola	Fan	1	
13	1272180	Cavo	Cable	1	
14	2100840	OR ø 56,82x2,62	O-Ring	1	
15	1982190	Condensatore 40 µF	Capacitor 40 µF	1	
16	394280	OR ø 12,42x1,78	O-Ring	1	
17	2021480	Passacavo	Gland	1	
18	1460340	Convogliatore	Conveyor	1	
19	2440460	Passacavo antipiega	Gland	1	
21	2320280	Interruttore 8A	Switch 8A	1	
22	2320270	Coperchio scatola interr.	Switch box cover	1	
23	2020570	Vite autof. M 4x12	Screw	3	
25	1262400	Rosetta ø 4	Washer	1	
26	2320131	Scatola interruttore	Switch box	1	TSS
29	660170	OR ø 31,42x2,62	O-Ring	1	
32	4815	Motore elettrico	Electric motor	1	5

Pos.	Cod. Part n°	Denominazione	Description	Q.tà Q.ty	Note Vedi / See

Legenda

⑤ 240 V/50Hz - Aust/Nzl