

VC30 Vacuum Cleaner 30L Without Power Socket

Drawing Reference	Part Number	Description
1	VC30-1	Handle assem.
2	VC30-2	Switch
3	VC30-3	Plate II
4	VC30-4	Foam
5	VC30-5	Foam
6	VC30-6	Sealing
7	VC30-7	Motor
8	VC30-8	Capacitor & Inductor
9	VC30-9	Sealing
10	VC30-10	Cover
11	VC30-11	Tray
12	VC30-12	Foam
13	VC30-13	Cup
14	VC30-14	Lower Cover assem.
15	VC30-15	Top Cover
16	VC30-16	Foam
17	VC30-17	Fan assem.
18	VC30-18	Frame
19	VC30-19	Foam
20	VC30-20	Plate I
21	VC30-21	Power cable
22	VC30-22	Pressure plate assem.
23	VC30-23	Clamp
24	VC30-24	Suction seat assem.
25	VC30-25	30L tank plastic
26	VC30-26	Water drain
27	VC30-27	Foot (w/slot)
28	VC30-28	Foot (w/o slot)
29	VC30-29	Cable hook

