

VC30A Vacuum Cleaner 30L With Power Socket

Drawing Reference	Part Number	Description
1	VC30A-1	Handle Assembly
2	VC30A-2	Inner Connector
3	VC30A-3	Switch
4	VC30A-4	Socket Assembly
5	VC30A-5	Switch
6	VC30A-6	Plate II
7	VC30A-7	Foam
8	VC30A-8	Foam
9	VC30A-9	Sealing
10	VC30A-10	Motor
11	VC30A-11	Capacitor & Inductor
12	VC30A-12	Sealing
13	VC30A-13	Cover
14	VC30A-14	Tray
15	VC30A-15	Foam
16	VC30A-16	Cup
17	VC30A-17	Lower Cover Assembly
18	VC30A-18	Top Cover
19	VC30A-19	Foam
20	VC30A-20	Fan Assembly
21	VC30A-21	Frame
22	VC30A-22	Foam
23	VC30A-23	Plate I
24	VC30A-24	PCB Board Assembly
25	VC30A-25	Power Cord
26	VC30A-26	Pressure Plate Assembly
27	VC30A-27	Clamp
28	VC30A-28	Suction Seat Assembly
29	VC30A-29	30L Tank - plastic
30	VC30A-30	Water Drain
31	VC30A-31	Floor (with slot)
32	VC30A-32	Cable Hook

